

THE ONE AND ONLY
Gazillion
Bubbles

GAZOOKA
Ultimate Bubble Blower™

Steps to operate your Gazooka™

Step 1:

Insert 6 "AA" batteries (not included) into battery compartment on body. (Diagram 1)

Note: Please make sure batteries are inserted with correct polarity. Recommend to use alkaline batteries for better performance.



Diagram 1

Step 2:

Fill up the handle with bubble solution. (Diagram 2)



Diagram 2

Step 3:

Twist and secure the handle, filled with solution into the opening. (Diagram 3)



Diagram 3

Step 4:

Hold Gazooka at level position and only tilt upward slightly.

Step 5:

Before blowing bubbles, hold trigger for 30 seconds to ensure wand is wet enough, then release & pull (might take several times) until bubble starts. (Diagram 4)



Diagram 4

Step 6:

In order to keep your Gazooka™ working properly, be sure to clean it out with water after play. (Diagram 5)

Note: Use a small paper or plastic cup and fill with water.

Insert plastic tube into the cup of water and hold the trigger back for approximately 15-20 seconds until you see water flowing out near the wand.

Repeat this step several times until the wand is clean.

IMPORTANT NOTES:



When you are playing with the Gazooka, do not point it downward or vertically. Heavy dripping will occur in front end.



Do not turn the Gazooka on its side, otherwise, leakage will occur from the body.



When you are not using the Gazooka, do not lay on its side, otherwise, internal components could be damaged by leaking solution.



Do not point the Gazooka upwards or vertically, otherwise, leakage may occur from the body.



Diagram 5

WARNING:
CHOKING HAZARD – Small parts.
Not for children under 3 yrs.

- When bubbles are not blowing away from the wand easily, replace with new batteries.
- Works best with Gazillion Bubbles green solution.

ITEM NO. 32796
Printed in China